

Best Management Practices for Engine Service Facilities

1. Sweep floors prior to floor wash down to pick up excessive oil and sand.



2. Know location and how to use and dispose of absorption products to clean any spills.



3. Properly dispose of oils and other wastes into designated containers without spilling.



4. Funnels or pumps shall be used to transfer automotive or other commercial or industrial fluids and chemicals.



5. Drip pans or containers shall be kept under the vehicles at all times during maintenance. Drip pans or containers shall be kept under stored or out of service vehicles awaiting restoration or service if leakage is suspected.



6. Spent or spilled automotive or other commercial or industrial fluids and chemicals shall not be washed down a drain.
7. No wastewater, fluids or other substances from commercial and industrial operations containing hazardous wastes, heavy metals, or other prohibited discharge shall enter the interceptor or any drain tied to the City's wastewater system.
8. Signs shall be posted in process areas with floor drains and above sinks prohibiting the discharge of oil and other chemical waste down the drains.

